

Tools Needed

- Phillips Screwdriver
- Putty Knife

STEP 1



Determine which side of the screen frame needs to be raised or lowered to eliminate any gaps or uneven reveals between the screen and frame.

STEP 2



On the left and right sides of the screen frame, there are holes that allow adjustment of the rollers. Using a Phillips screwdriver, adjust the rollers until the frame is properly aligned.

STEP 3



Check the screen for proper operation.

STEP 1



To remove the screen, lift the screen up.

STEP 2



Using a putty knife, gently lift the rollers up to help them clear the track. **IMPORTANT!** Be careful not to damage the frame with the putty knife.

STEP 3



Remove the screen.

STEP 1



To replace the screen, simply repeat the above steps in reverse: Lift the screen up into the frame.

STEP 2



Using a putty knife, gently lift the rollers to help them clear the track.

STEP 3



Place the screen into place.

STEP 4



Check for proper operation.