

# INSTALLATION INSTRUCTIONS

**Caution: Window must be properly sealed from water before casing can be installed.  
This accessory is not meant to be used as a barrier against water infiltration.**

1. Ensure that the brickmould surface is clear of debris and clean.
2. Inspect the back of casing to locate steel clips – this area is where the force in step 5 will need to be applied.
3. Pull backing off of adhesive on the bull nose as shown in Figure 1.
4. As shown in Figure 2, tilt head of casing away from the window and apply sill end first so that the bull nose lip sits on the brickmould just under the weeps.
5. Apply 20-30lbs of pressure (using hands only - no tools) at all clip locations to securely engage the casing onto brickmould profile – see Figure 3.
6. Apply a gentle force in the opposite direction to verify clip retention.

