

Tools Needed

- Silicone Caulk & Gun
- Utility Knife

STEP 1



Remove the sash. Locate the two weather strips on the bottom of the sash.

STEP 2



Remove the worn weatherstripping from the track that holds it in place.

STEP 3



Insert the new weatherstripping into the track on the sash.

STEP 4



If the weatherstripping is too long, cut the excess so that the strip is flush with the edge of the sash.

STEP 1



Caulking Tips: With the sash removed, locate the jam adjuster screw holes on each side of the frame.

STEP 2



Fill the jam adjuster areas with caulk.

STEP 3



Remove excess caulk so it's flush with the track.

STEP 4



Check for any predrilled holes in the frame. If there are any empty pre-drilled holes, fill them with caulk and remove the excess caulk.

STEP 5



Exterior Caulking: Caulk where the outside of the frame meets the house, seal with silicone for a perimeter seal. (Be sure the seal is consistent all the way around).

STEP 6



IMPORTANT! Be careful not to caulk over the weep holes, and make sure they are clear and free of debris.