



STORMBREAKER PLUS® 2-LITE SLIDER INSTALLATION INSTRUCTIONS

simonton.com/coastal-installation

1. Install sash retaining brackets, at the top of the operating sash, on the same side as the locks. Brackets should be positioned so that the 90° piece of the bracket is no longer viewable. (See Fig. 1) Use three of the #12 x 1" Self-Tapping screws provided to install each bracket.

NOTE: There are dimples on the sash showing where each of the screws should be placed.

Tools Needed



Safety Glasses



Drill

Anchorage screws needed
(quantity needed can be found on Floridabuilding.org)

Hardware Bag Contents

Description	Quantity
Right or Left Sash Retaining Bracket.....	Qty: 1
Install Screw Gasket.....	Qty: 4
#12 x 1" Self-Tapping Screw	Qty: 3



Figure 1.

