

Tools Needed

- Flathead Screwdriver

Determining If Your Patio Door Needs Adjustment

- Too much movement between the panel and frame when the door is locked.
- The panel abuts the frame too tightly when the door is locked.
- The door will not latch when you try to close it.

STEP 1



Open the door and locate the anti-slam pin on the edge.

STEP 2



Depress the anti-slam pin. The latches will now be visible when you move the lock.

STEP 3



Locate the adjustment screws. Using a flathead screwdriver, turn the screws clockwise or counter-clockwise to adjust the latch further in or out.

STEP 4



Trigger the latches back into the door, close the door, latch it and check for proper fit. The latch may require more adjusting to achieve the right fit.